```
In [119... #Imports needed libraries
          import rasterio
          from rasterio import plot
          import matplotlib
          from matplotlib import pyplot as plt
          import numpy as np
          %matplotlib inline
          import os
          from skimage import io, exposure
          #Opens the rasters
          band2=rasterio.open('Subsets/B2subset.tif')
          band4=rasterio.open('Subsets/B4subset.tif')
In [121...
          #Defining needed bands
          green=rasterio.open('Subsets/subsetB2.tif').read(1).astype('float64')
          nir=rasterio.open('Subsets/subsetB4.tif').read(1).astype('float64')
In [122...
          #Functions were taken from GEO468E_notebook.ipynb
          def normalize(array):
              array_min, array_max = array.min(), array.max()
              return (array - array_min) / (array_max - array_min)
          def image_histogram(img):
              Plot image histogram
              Input:
              img - 2D array of uint16 type
              co, ce = exposure.histogram(img)
               fig = plt.figure(figsize=(10, 7))
               fig.set_facecolor('white')
              plt.plot(ce[1::], co[1::])
              plt.show()
          def image_adjust_brightness(img, limit_left, limit_right, color_map, title):
              Adjust image brightness and plot the image
              Input:
               img - 2D array of uint16 type
              limit_left - integer
              limit_right - integer
              color_map - string
              title - string
               img_ha = exposure.rescale_intensity(img, (limit_left, limit_right))
               fig = plt.figure(figsize=(10, 10))
               fig.set_facecolor('cyan')
              plt.imshow(img_ha, cmap=color_map)
              plt.title(title)
              plt.colorbar()
              plt.show()
               return img_ha
          def image_show(img, color_map, title):
              Show image
              Input:
               img - 2D array of uint16 type
              color_map - string
              title - string
               fig = plt.figure(figsize=(10, 10))
               fig.set_facecolor('white')
               plt.imshow(img, cmap=color_map)
               plt.title(title)
               plt.show()
          def image_histogram(img):
              Plot image histogram
              Input:
              img - 2D array of uint16 type
              co, ce = exposure.histogram(img)
               fig = plt.figure(figsize=(20, 7))
               fig.set_facecolor('white')
              plt.plot(ce[1::], co[1::])
               plt.show()
In [123...
          #Calculates ndwi index
          ndwi=np.where(
               (green+nir)==0.,
               (green-nir)/(green+nir))
          ndwi[:5,:5]
Out[123... array([[0.01775974, 0.02652753, 0.01775974, 0.00854808, 0.01775974],
                 [0.00854808, 0.00883257, 0.01775974, 0.02652753, 0.02652753],
                 [0.00883257, 0.00883257, 0.02652753, 0.02652753, 0.01775974],
                 [0.00854808, 0.01775974, 0.01775974, 0.00854808, 0.02652753],
                 [0.02652753, 0.02652753, 0.01731871, 0.00854808, 0.00854808]])
In [124...
          #Shows the results
          image_show(ndwi,"gray","NDWI Image")
                                            NDWI Image
           250
           500
           750
          1000
          1250
          1500
          1750
          2000
                              500
                                                        1250
                                                                         1750
                      250
                                               1000
                                                                 1500
 In [ ]: #Exports the ndwi image
          ndwi_img=rasterio.open("Outputs/NDWI.tif",'w',driver='gtiff',
                                    width=band4.width,
                                    height = band4.height
                                    count=1, crs=band4.crs,
                                    transform=band4.transform,
                                    dtype='float64')
          ndwi_img.write(ndwi,1)
In [126...
          #Closes image
          ndwi_img.close()
In [127...
          #Opens the exported output
          ndwitif=rasterio.open('Outputs/NDWI.TIF').read(1).astype('float64')
          image_show(ndwitif,"gray","NDWI Image Output")
                                         NDWI Image Output
           200
           400
           600
           800
          1000
                                                       600
                                                                     800
                           200
                                         400
                                                                                  1000
In [128... #Histogram
          image_histogram(ndwi)
          400000
          300000
```

200000

100000

-0.5

-0.3

-0.2

0.0